

Please Read This First

If you have problems setting up your AMIGA™ Computer or have problems getting your AMIGA Computer to run:

Check *ALL* your connections:

Do they match the connections shown in the diagram on the reverse side of this sheet?

Are all power switches turned ON? Are the monitor/TV and the Amiga “on” lights on?

If you're using a TV set for your display, is the switch on the computer/TV switchbox set to computer? Is the TV tuned to either Channel 3 or Channel 4? Is the TV modulator switched to the same channel as the TV? (You should tune the TV, and the TV modulator, to whichever channel—3 or 4—is NOT used by the TV stations in your geographical area.)

If you're using a video monitor for your display, are all monitor switches set properly?

For complete instructions on setting up and turning on your AMIGA Computer and its peripheral equipment refer to your copy of the user's manual, “Introduction to Amiga.™”

